

<b>A</b>	A/C* .....	220
	ABS.....	197
	ACCESSORY mode .....	134
	Air conditioning filter .....	426
	Air conditioning system	
	Air conditioning filter .....	426
	Automatic air conditioning system .....	220
	Airbags	
	Airbag operating conditions.....	97
	Airbag precautions for your child.....	101
	Airbag warning light .....	464
	Curtain shield airbag operating conditions.....	97
	Curtain shield airbag precautions .....	101
	Front passenger occupant classification system.....	106
	General airbag precautions .....	101
	Locations of airbags.....	94
	Modification and disposal of airbags.....	105
	Proper driving posture .....	92, 101
	Side airbag operating conditions.....	97
	Side airbag precautions .....	101
	SRS airbags .....	94
	Alarm .....	88
	Antenna* .....	238
	Anti-lock brake system .....	197
	Armrest.....	351
	Ashtrays.....	346
	Audio input*.....	275
	Audio system*	
	Antenna .....	238
	Audio input .....	275

AUX port.....	275
Bluetooth® audio .....	280
CD player/changer .....	241
iPod .....	256
MP3/WMA disc.....	248
Optimal use .....	273
Portable music player .....	275
Radio .....	233
Steering wheel audio switch.....	277
USB memory .....	264
USB port .....	256, 264
Automatic air conditioning system* .....	220
Automatic headlight leveling system .....	165
Automatic light control system.....	162
Automatic transmission	
Automatic transmission .....	138
If the shift lever cannot be shifted from P.....	497
M mode .....	143
AUX port* .....	275
Auxiliary box .....	339

<b>B</b>	Back-up lights	
	Wattage .....	522
	Battery	
	Checking.....	406
	If the vehicle has a discharged battery .....	502
	Preparing and checking before winter.....	214
	Bluetooth® audio* .....	280
	Bluetooth® phone* .....	299
	Bottle holders.....	339

<b>Brake</b>	
Fluid .....	404
Parking brake .....	148
<b>Brake assist</b> .....	197

**C**

<b>Care</b>	
Exterior .....	378
Interior .....	381
Seat belts .....	382
<b>Cargo capacity</b> .....	210
<b>Cargo hooks</b> .....	356
<b>CD changer*</b> .....	241
<b>CD player*</b> .....	241
<b>Chains</b> .....	214
<b>Child restraint system</b>	
Booster seats, definition .....	111
Booster seats, installation .....	117
Convertible seats, definition .....	111
Convertible seats, installation .....	117
Front passenger occupant	
classification system .....	106
Infant seats, definition .....	111
Infant seats, installation .....	117
Installing CRS with lower	
anchorage .....	116
Installing CRS with seat belts .....	117
Installing CRS with top straps .....	121
<b>Child safety</b>	
Airbag precautions .....	101
Battery precautions .....	408, 504
Child restraint system .....	111
Child-protectors .....	47
How your child should wear	
the seat belt .....	67

Installing child restraints .....	115
Moon roof precautions .....	82
Power window lock switch .....	76
Power window precautions .....	78
Removed electronic key battery	
precautions .....	430
Seat belt comfort guide .....	65
Seat belt extender precautions .....	69
Seat belt precautions .....	68
Seat heater precautions .....	350
Trunk precautions .....	52
<b>Child-protectors</b> .....	47
<b>Cigarette lighter</b> .....	347
<b>Cleaning</b>	
Exterior .....	378
Interior .....	381
Seat belts .....	382
<b>Clock</b> .....	342
<b>Coat hooks</b> .....	354
<b>Compass</b> .....	365
<b>Condenser</b> .....	404
<b>Console box</b> .....	335
<b>Cooling system</b>	
Engine overheating .....	505
<b>Cornering assist sensors</b> .....	191
<b>Cruise control</b>	
Cruise control .....	173
Dynamic radar cruise control .....	177
<b>Cup holders</b> .....	337
<b>Curtain shield airbags</b> .....	94
<b>Customizable features</b> .....	538

\*: For vehicles with a navigation system, refer to the "Navigation System Owner's Manual".

## D

Daytime running light system .....	164
Defogger*	
Rear window.....	228
Side mirrors .....	228
Dimension.....	512
Dinghy towing .....	217
Display	
Dynamic radar cruise control .....	177
Satellite switch mode.....	343
Trip information .....	158
Warning message.....	473
Do-it-yourself maintenance .....	390
Door courtesy lights	
Door courtesy lights.....	330
Wattage.....	522
Door pockets.....	339
Doors	
Door lock.....	32, 43, 46
Door windows .....	76
Side mirrors .....	74
Driver's seat belt reminder light ....	466
Driving	
Correct posture .....	92
Procedures .....	126
Driving position memory .....	55

## E

Electric power steering .....	197
Electronic key	
If the electronic key does not operate properly .....	499
Emergency flashers	
Switch .....	454
Emergency, in case of	
If a warning message is displayed .....	473

If the electronic key does not operate properly.....	499
If the engine will not start.....	496
If the shift lever cannot be shifted from P.....	497
If the vehicle has a discharged battery .....	502
If the warning buzzer sounds.....	463
If the warning light turns on.....	463
If you have a flat tire .....	487
If you lose your keys .....	498
If you think something is wrong .....	461
If your vehicle becomes stuck ....	508
If your vehicle has to be stopped in an emergency .....	509
If your vehicle needs to be towed.....	455
If your vehicle overheats.....	505

## Engine

ACCESSORY mode.....	134
Compartment .....	396
Engine switch.....	134
Hood.....	393
How to start the engine .....	134
Identification number .....	513
If the engine will not start.....	496
Ignition switch .....	134
Overheating .....	505

## Engine compartment cover .....

## Engine coolant

Capacity .....	517
Checking.....	402
Preparing and checking before winter.....	214

Engine coolant temperature gauge .....	150
Engine immobilizer system .....	86
Engine oil	
Capacity .....	516
Checking .....	399
Preparing and checking before winter .....	214
EPS .....	197
Event data recorder .....	21

<b>F</b> First-aid kit storage belt .....	356
Floor mat .....	355
Fluid	
Brake .....	404
Washer .....	409
Fog lights	
Switch .....	166
Wattage .....	522
Footwell lights .....	330
Front fog lights	
Switch .....	166
Wattage .....	522
Front passenger occupant classification system .....	106
Front passenger's seat belt reminder light .....	466
Front seats	
Adjustment .....	54
Driving position memory .....	55
Seat position memory .....	59
Front turn signal lights	
Switch .....	147
Wattage .....	522

Fuel	
Capacity .....	515
Fuel gauge .....	150
Fuel pump shut off system .....	462
Gas station information .....	576
Information .....	523
Refueling .....	83
Fuel door .....	83
Fuel filler door .....	83
Fuel pump shut off system .....	462
Fuses .....	431

<b>G</b> Garage door opener .....	359
Gas station information .....	576
Gauges .....	150
Glove box .....	335
Glove box light .....	335

<b>H</b> Hands-free system for mobile phone* .....	299
Hazard lights	
Switch .....	454
Head restraints	
Adjusting .....	61
Headlight aim .....	445
Headlight cleaner .....	172
Headlights	
Discharge headlight precautions .....	451
Replacing light bulbs .....	447
Switch .....	162
Wattage .....	522

\*: For vehicles with a navigation system, refer to the "Navigation System Owner's Manual".

Heaters	
Seat heaters.....	349
Side mirrors.....	228
Hill-start assist control .....	197
Hood .....	393
Hooks	
Cargo.....	356
Coat .....	354
Shopping bag.....	356
Horn .....	149

<b>I</b> I/M test.....	389
Identification	
Engine .....	513
Vehicle.....	513
Ignition switch.....	134
Illuminated entry system .....	330
Indicator lights.....	154
Initialization	
Items to initialize.....	543
Inside rear view mirror .....	72
Interior lights	
Interior lights.....	330
Switch .....	332
Wattage.....	522

<b>J</b> Jack	
Positioning a floor jack.....	394
Vehicle-equipped jack .....	487
Jack handle.....	487

<b>K</b> Keyless entry .....	43
Keys	
Electronic key .....	28
Engine switch .....	134
If the electronic key does not operate properly.....	499
If you lose your keys .....	498
Key number.....	28
Keyless entry.....	43
Keys.....	28
Mechanical key .....	29
Wireless remote control key.....	43

<b>L</b> Lexus Enform*	
Light bulbs	
Replacing .....	447
Wattage .....	522
Lights	
Door courtesy lights.....	330
Emergency flasher switch.....	454
Fog light switch .....	166
Hazard light switch .....	454
Headlights switch.....	162
Interior light switch .....	332
Outer foot lights.....	330
Personal light switch.....	332
Replacing light bulbs .....	447
Shift lever light.....	330
Turn signal lever.....	147
Vanity lights.....	341
Wattage .....	522
Load capacity.....	213

<b>M</b>	<b>Maintenance</b>	
	Do-it-yourself maintenance.....	390
	General maintenance.....	386
	Maintenance data .....	512
	Maintenance requirements.....	384
	<b>Maintenance data.....</b>	<b>385</b>
	<b>Meter</b>	
	Instrument panel light control.....	152
	Meters.....	150
	<b>Micro dust and pollen filter* .....</b>	<b>224</b>
	<b>Mirrors</b>	
	Inside rear view mirror .....	72
	Side mirror heater .....	228
	Side mirrors.....	74
	Vanity mirrors .....	341
	<b>Moon roof.....</b>	<b>79</b>
	<b>MP3 disc* .....</b>	<b>248</b>
	<b>Multi-information display.....</b>	<b>157</b>
<b>N</b>	<b>Noise from under vehicle .....</b>	<b>19</b>
<b>O</b>	<b>Odometer .....</b>	<b>150</b>
	<b>Oil</b>	
	Engine oil.....	399
	<b>Opener</b>	
	Fuel filler door .....	83
	Hood.....	393
	Trunk.....	50
	<b>Outer foot lights</b>	
	Outer foot lights.....	330
	Wattage .....	522

	<b>Outside rear view mirrors</b>	
	Adjusting and folding.....	74
	Mirror position memory.....	55
	<b>Outside temperature display .....</b>	<b>158</b>
	<b>Overhead console .....</b>	<b>336</b>
	<b>Overhead courtesy lights</b>	
	Overhead courtesy lights.....	330
	Wattage.....	522
	<b>Overheating, Engine.....</b>	<b>505</b>
<b>P</b>	<b>Parking assist sensors* .....</b>	<b>191</b>
	<b>Parking brake.....</b>	<b>148</b>
	<b>Parking lights</b>	
	Replacing light bulbs.....	447
	Switch.....	162
	Wattage.....	522
	<b>PCS .....</b>	<b>203</b>
	<b>Personal lights</b>	
	Switch.....	332
	<b>Power outlet.....</b>	<b>348</b>
	<b>Power windows .....</b>	<b>76</b>
	<b>Pre-collision system.....</b>	<b>203</b>

\*: For vehicles with a navigation system, refer to the "Navigation System Owner's Manual".

<b>R</b>	Radars cruise control.....	177
	Radiator .....	404
	Radio* .....	233
	RDS* .....	235
	Rear turn signal lights	
	Replacing light bulbs.....	447
	Wattage.....	522
	Rear view mirror	
	Compass .....	365
	Rear window defogger* .....	228
	Replacing	
	Electronic key battery.....	429
	Fuses .....	431
	Light bulbs.....	447
	Reporting safety defects for	
	U.S. owners.....	546

<b>S</b>	Safety connect .....	369
	Seat belts	
	Adjusting the seat belt.....	65
	Automatic locking retractor.....	66
	Child restraint system	
	installation .....	115
	Cleaning and maintaining	
	the seat belts.....	382
	Emergency locking retractor.....	66
	How to wear your seat belt.....	64
	How your child should wear	
	the seat belt.....	67
	Pregnant women,	
	proper seat belt use.....	66
	Reminder light.....	466
	Seat belt extenders .....	67
	Seat belt pretensioners.....	65

Seat heaters.....	349
Seat position memory.....	59
Seating capacity.....	213
Seats	
Adjustment .....	54
Adjustment precautions .....	54
Child seats/child restraint	
system installation.....	115
Cleaning.....	381
Driver's seat position memory .....	55
Front passenger seat position	
memory .....	59
Head restraints.....	61
Properly sitting in the seat.....	92
Seat heaters .....	349
Service reminder indicators .....	154
Shift lever	
If the shift lever cannot be	
shifted from P.....	497
Transmission.....	138
Shift lever light .....	330
Shift lock system.....	497
Shopping bag hooks .....	356
Side airbags .....	94
Side marker lights	
Switch.....	162
Side mirrors	
Adjusting and folding.....	74
Mirror position memory .....	55
Smart access system with	
push-button start	
Entry function .....	32
Starting the engine.....	134
"SOS" button.....	369

<b>Spare tire</b>	
Inflation pressure .....	420
Storage location.....	487
<b>Spark plug</b> .....	518
<b>Specifications</b> .....	512
<b>Speedometer</b> .....	150
<b>Steering wheel</b>	
Adjustment .....	70
Audio switches .....	277
Steering wheel position	
memory .....	55
<b>Storage feature</b> .....	334
<b>Stuck</b>	
If your vehicle becomes stuck ...	508
<b>Sun visors</b> .....	340
<b>Sunshade</b> .....	80
<b>Switch</b>	
Emergency flasher switch.....	454
Engine switch .....	134
Fog light switch.....	166
F-sport mode total control	
switch.....	140, 199
Hazard light switch.....	454
Ignition switch.....	134
Light switches.....	162

<b>T</b>	<b>Tachometer</b> .....	150
	<b>Tail lights</b>	
	Switch.....	162
	<b>Talk switch*</b> .....	304
	<b>Telephone switch*</b> .....	304
	<b>Theft deterrent system</b>	
	Alarm.....	88
	Engine immobilizer system.....	86
	<b>Theft prevention labels</b> .....	91
	<b>Tire inflation pressure</b> .....	420
	<b>Tire information</b>	
	Glossary .....	531
	Size.....	528
	Tire identification number .....	528
	Uniform tire quality grading .....	529

\*: For vehicles with a navigation system, refer to the "Navigation System Owner's Manual".



Tires

Chains ..... 214

Checking ..... 410

If you have a flat tire ..... 487

Inflation pressure ..... 420

Inflation pressure sensor ..... 410

Information ..... 526

Replacing ..... 487

Rotating tires ..... 410

Size ..... 521

Snow tires ..... 214

Tools ..... 487

Total load capacity ..... 213

Towing

    Dinghy towing ..... 217

    Emergency towing ..... 455

    Trailer towing ..... 216

TRAC ..... 197

Traction control ..... 197

Transmission shift switches ..... 141, 143

Trip meter ..... 150

Trunk

    Extending trunk space ..... 352

    Opener ..... 50

Trunk light

    Trunk light ..... 51

    Wattage ..... 522

Turn signal lights

Replacing light bulbs ..... 447

Switch ..... 147

Wattage ..... 522

U

USB port\* ..... 256, 264

V

Vanity lights

    Vanity lights ..... 341

    Wattage ..... 522

Vanity mirrors ..... 341

VDIM ..... 197

Vehicle dynamics integrated  
    management ..... 197

Vehicle identification number ..... 513

Vehicle stability control ..... 197

Voice command switch ..... 304

VSC ..... 197

W

Warning buzzers

Brake system ..... 463

Open door ..... 466

Seat belt reminder ..... 466

## Warning lights

Anti-lock brake system .....	464
Brake assist system .....	464
Brake system .....	463
Charging system .....	464
Electric power steering system	
warning light .....	464
Low fuel level .....	466
Malfunction indicator lamp .....	464
Master warning light .....	466
Open door .....	466
Pre-collision system .....	464
Pretensioners .....	464
Seat belt reminder light .....	466
SRS airbags .....	464
Tire pressure warning	
light .....	466

## Warning messages

Automatic transmission	
fluid .....	477
Dynamic radar	
cruise control .....	475, 477
Engine oil level .....	477
Engine oil maintenance .....	477
Engine oil pressure .....	474
Engine oil temperature .....	474
Headlight .....	475
Hood .....	477
Intuitive parking assist .....	475, 477
Moon roof .....	477
Open door .....	477
Parking brake .....	477
Pre-collision system .....	475, 477
Smart access system with	
push-button start .....	483
Steering lock .....	475
Trunk .....	477
Washer fluid .....	477

## Washer

Checking .....	409
Preparing and checking	
before winter .....	214
Switch .....	168

Washing and waxing .....	378
--------------------------	-----

\*: For vehicles with a navigation system, refer to the "Navigation System Owner's Manual".

<b>Weight</b>	
Cargo capacity.....	210
Load limits .....	213
Weight .....	512
<b>Wheels .....</b>	<b>424</b>
<b>Window glasses .....</b>	<b>76</b>
<b>Window lock switch .....</b>	<b>76</b>
<b>Windows</b>	
Power windows.....	76
Rear window defogger .....	228
Washer .....	168
<b>Windshield wipers.....</b>	<b>168</b>
<b>Windshield wiper de-icer.....</b>	<b>229</b>
<b>Wireless remote control key</b>	
Replacing the battery .....	429
<b>WMA disc* .....</b>	<b>248</b>

\*: For vehicles with a navigation system, refer to the “Navigation System Owner’s Manual”.